E3620A-06-S

S E R V I C E N O T E

Supersedes: NONE

E3620A Lab Bench DC Power Supply

Serial Numbers: KR71804262 through KR09999999, MY4000001/MY40003871,SG40000001/SG40003871

POSSIBLE SHOCK HAZARD

WARNING

The AC power module can accidentally come out of the instrument creating a shock hazard.

To Be Performed By: Agilent- Service Center or Customer Qualified Personnel.

Parts Required:

P/N Description Qty.

5065-6978 AC Module Repair Kit 1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
PRIORITY SAFETY		
ACTION		STANDARDS:
CATEGORY:	X Immediately	LABOR: 0.5 Hours
	·	
LOCATION	X CUSTOMER INSTALLABLE	SERVICE [[]] RETURN USED [[]] RETURN
CATEGORY:	[[]] ON-SITE X SERVICE CENTER	INVENTORY: X SCRAP PARTS: X SCRAP [[]] SEE TEXT [[]] SEE
TEXT	A SERVICE SERVICE	SEE TEXT SEE TEXT
AVAILABILITY:	ALWAYS	AGILENT RESPONSIBLE UNTIL: ALWAYS
AUTHOR: (CP)	PRODUCT LINE: (PL33)	
ADDITIONAL INFORMATION:		

© AGILENT TECHNOLOGIES, INC. 2004 PRINTED IN U.S.A.



Page 2 of 3 E3620A-06-S

Situation:

If the AC line cord is forcefully pulled in a side-to-side direction the AC Module can be pulled out of the rear heatsink, exposing the conductors that carry AC line voltage.

Solution/Action:

Follow steps 1-4 below:





CAUTION: TEST FOR LOOSE AC MODULE

- 1. Make sure linecord is removed from outlet.
- 2. With linecord securely inserted in AC Module as shown, pull forcibly (2 times) in direction of arrow.

LOOSE AC MODULE

- If the AC Module pulls out from Unit as shown it will need to be replaced.
- 2. If the AC Module remains in place it does not need to be changed. Put a mark on the AC input label in the lower left hand corner with indelible ink to indicate that the AC module has been checked. This label can be found below the AC module.




REMOVE COVER

E3610/11/12/30A

Pry Rear Bezel and Front Panel away from Cover in four places. Then lift Cover off unit.

E3614/15/16/17/20A Pry Tabs out on rear of Top Cover and lift Cover off of the unit Page 3 of 3 E3620A-06-S



REPLACE MODULE with P/N 5065-6978. Before soldering perform "TEST FOR LOOSE AC MODULE" as shown in picture above. This will confirm that the new Module is secure. Solder wires and **REPLACE FUSE**.

100/120 VAC input- use Fuse P/N 2110-0702 (2 amps, 250 volts) E3610/11/12/14/15/16/17/20A 100/120 VAC input- use Fuse P/N 2110-0918 (1.6 amps, 250 volts) E3630A only 230 VAC input- use Fuse P/N 2110-0599 (1 amp, 250 volts) E3610/11/12/30A input -use Fuse P/N 2110-1346 (1 amp, 250 volts) E3614/15/16/17/20A

CAUTION: WIRING MUST BE CORRECT OR H TSINK COULD BE AT LINE POTENTIAL.

CAUTION: MAKE SURE SAFETY GROUND IS ATTACHED TO HEATSINK

After AC Module is soldered, replace cover and turn unit on. No calibration or specification verification is required.

Put a mark on the AC input label in the lower left hand corner with indelible ink to indicate that the AC module has been replaced. This label can be found below the AC module.