

S E R V I C E N O T E

SUPERSEDES: NONE

E3611A 30W Lab Bench DC Power Supply

Serial Numbers: KR30702078/KR64304626

To eliminate the oscillation from the power supply's output.

To be performed by: Agilent-Qualified Personnel

Duplicate Service Notes: E3610A-04

Situation:

The power supply's output shows an oscillation when either the (+) or (-) output terminal is connected to the ground terminal.

Solution / Action:

Remove the C4 and C5 capacitors on the main PC board.

DATE: March 1997

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
MODIFICATION RECOMMENDED			
ACTION CATEGORY:	<input checked="" type="checkbox"/> IMMEDIATELY <input type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS:	LABOR 1.0 Hours
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY:	<input type="checkbox"/> RETURN <input checked="" type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	USED PARTS:	<input type="checkbox"/> RETURN <input checked="" type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AUTHOR: NKP	ENTITY: Y300	AGILENT RESPONSIBLE UNTIL: March 1999	
		ADDITIONAL INFORMATION:	

